

DMR Conventional Radio GPS Application Notes



Copyright Information

Hytera is the trademark or registered trademark of Hytera Communications Corporation Limited in the People's Republic of China (PRC) and/or other countries or areas. Hytera retains the ownership of its trademarks and product names. All other trademarks and/or product names that may be used in this manual are properties of their respective owners.

The product described in this manual may include Hytera's computer programs stored in memory or other media. Laws in PRC and/or other countries or areas protect the exclusive rights of Hytera with respect to its computer programs. The purchase of this product shall not be deemed to grant, either directly or by implication, any rights to the purchaser regarding Hytera's computer programs. Hytera's computer programs may not be copied, modified, distributed, decompiled, or reverse-engineered in any manner without the prior written consent of Hytera.

Disclaimer

Hytera endeavors to achieve the accuracy and completeness of this manual, but no warranty of accuracy or reliability is given. All the specifications and designs are subject to change without notice due to continuous technological development. No part of this manual shall be copied, modified, translated, or distributed in any manner without the express written permission of us.

We do not guarantee, for any particular purpose, the accuracy, validity, timeliness, legitimacy or completeness of the third-party products and contents involved in this manual.

If you have any suggestions or would like to receive more information, please visit our website at: http://www.hytera.com.

Contents

Documentation Information 1	
1. Overview	,
1.1 Introduction	
1.2 Applicable Models	
1.3 Principle	
1.4 Versions	
1.5 Restrictions	
1.6 References	
2. Configuration	
2.1 Configuration Tool	
2.2 Configuring Common Parameters	
2.3 Configuring Parameters Related to Location Query	,
2.4 Configuring Parameters Related to Location Information Report	
3. Application	1
Abbreviations	

Documentation Information

This section describes the conventions and revision history of this document.

Conventions

Icons

Icon	Description
ОТір	Indicates information that can help you make better use of your product.
Note	Indicates references that can further describe the related topics.
	Indicates situations that could cause data loss or equipment damage.
Warning	Indicates situations that could cause minor personal injury.
Danger	Indicates situations that could cause major personal injury or even death.

Notations

Item	Description
Bold	The text in boldface denotes the name of a hardware button or a software interface element. For example, press the PTT key.
->	The symbol directs you to access a multi-level menu. For example, to select "New" from the "File" menu, we will describe it as follows: "File -> New".

Revision History

Version	Date	Description					
R3.0	September, 2018	 Added TF Card GPS Record, Location Info Priority, Single GPS and Single GPS Encrypt/Decrypt features. The radio without positioning chip can query location of the radios with positioning chip through Call Location and Query Location features. Modify CPS path of RSSI Report and Voice w/Location. Software Version: R9.0 					

Version	Date	Description					
R2.0	March 15, 2018	 Added Call Location feature. Modified the following parameter names: "RRS & GPS Radio ID" modified as "Control Center ID" "GPS Port" modified as "Location Port" "GPS Revert Channel" modified as "Location Info Revert Channel" "Voice with GPS" modified as "Voice w/Location" "In Call GPS Revert" modified as "In Call Location Revert" 					
R1.0	January 3, 2017	Initial Release.					

1. Overview

1.1 Introduction

The Global Positioning System (GPS) feature facilitates location-based applications, allowing visible dispatch by the dispatch station. When this feature is enabled, the user can obtain its real-time location information or query that of another radio, and can report location to another radio or to the dispatch station.

1.2 Applicable Models

The GPS feature is available to the following models.

• Radios with positioning chip support all GPS features.

The ninth character of the model number is G, C or R, for example, PD980-T00C000D-MB0000-Ux-0-D.

- > "G" means the radio supports GPS.
- > "C" means the radio supports both GPS and BeiDou Navigation Satellite System (COMPASS).
- > "R" means the radio supports both GPS and Global Navigation Satellite System (GLONASS).

To view the model number, click **Radio Information** in Customer Programming Software (CPS) after the radio is connected. For more information, please contact Hytera or your supplier.

- Radios without positioning chip can query location of the radios with positioning chip through Call Location or Query Location.
- Repeater

Currently, the GPS feature is available only to RD96X, which only reports location at preset time interval.

This document takes PD98X as an example.

1.3 Principle

Each satellite continually broadcasts a signal with pseudorandom code and transmission time. The radio with positioning chip receives this signal and calculates its location, and sends the location information to the dispatch station or another radio in the system.

1.4 Versions

• R9.0: TF Card GPS Record, Single GPS, Singal GPS Encrypt features added. The radios without positioning chip support Call Location and Query Location features.

- R8.5: Call Location feature added. The parameter names "RRS&GPS Radio ID", "GPS Port", "GPS Revert Channel", "Voice with GPS" and "In Call GPS Revert" are modified as "Control Center ID", "Location Port", "Location Info Revert Channel", "Voice w/Location" and "In Call Location Revert" respectively.
- R8.0: Voice with GPS and Query Location features added.
- R6.0: COMPASS supported.
- R5.5: Quick GPS and GPS Data Compression features added.
- R5.0: GLONASS supported.
- R4.0: Time Zone feature added.
- R3.0: Application Programming Interface (API) for GPS-based dispatch and control, GPS Revert Channel, GPS Automatic Update and GPS Active Report features added.
- R2.0: GPS icon, Position View and GPS Msg added.

1.5 Restrictions

- The radios without positioning chip can query location of the radios with positioning chip through Call Location or Query Location only.
- The satellite signal reception is subject to the environment in which the radio is located. The signal strength may be low in such unfavorable places as basement, train, or subway.

1.6 References

- CPS Help (on-line)
- Release Notes

2. Configuration

This chapter describes how to configure the radio and the repeater. For the dispatch station, refer to relevant documents.

2.1 Configuration Tool

CPS V9.00.07.712.iM or later

2.2 Configuring Common Parameters

Step 1 Enable the GPS feature.

CPS Path: Conventional -> General Setting -> Accessories -> GPS.

Parameters: GPS. Refer to CPS Help for detailed description.

GPS	
	GPS 🔽

Step 2 Select the positioning system and set the GPS stabilized time.

CPS Path: Common -> Accessories -> GPS.

Parameters: Positioning System Setting and GPS Stabilized Time.

- 🗐 Radio Information		Device Name	Alias	Ŧ
Setting Feature Control Setting Microphone/VOX Setting USetting Setting Setti	GPS	Positioning System Setting GPS Stabilized Time [s]	COMPASS+GPS 0	•

The Positioning System Setting is used to set the positioning system, and only available for the radios that support COMPASS or GLONASS.

The GPS Stabilized Time is the time in which the radio considers satellite signal invalid for positioning. Because the positioning needs time, there will be deviation when the radio first receives the broadcasted signal. The GPS Stabilized Time helps to improve location accuracy of the radio.



If accurate location is required, it is recommended to set GPS Stabilized Time at or more than 5.

2.3 Configuring Parameters Related to Location Query

Step 1 Configure the parameters for location information display, and enable or disable TF Card GPS Record and GPS Data Compression.

CPS Path: Conventional -> General Setting -> Accessories -> GPS.

S a hala fie Ea narameter descriptio the Table bel

Padia Information	below lighte. For parameter descrip	Stioli, see the 18	ioie below.
Radio information	GPS	GF TF Card GPS Reco GPS Data Compressi Speed U	rs 🔽 rd 🗌 on 🔽 hit Km/h 🗸
····합 Telemetry ····합 One Touch (····· 등 Menu ····· 에 UI Indication ····· 에 Voice Notify	Call / Menu	GPS Update Time GPS Display U	s] 5 A
Parameter	Description		Setting
	This feature is used to collect GPS radio management.	S data for De	fault: Unchecked. te:
TF Card GPS Record	 With the feature enabled, the radio GPS data in the TF card (Micro S according to the following preset parameters. When GPS is enabled, the rad GPS data according to Time, I and Relationship Between Tim Distance set in GPS Trigger (s in section 2.4). When Quick GPS is enabled, records GPS data according to Interval Time (see Step 4 in section 2.4). 	o records D card) io records Distance ne and see Step 2 the radio o Report ection	This feature is available for PD78XE and PD98X only. This parameter is available only when GPS is selected. Use can use SmartDispatch to read and view radio tracks on the map. For

In emergency mode, the radio records

GPS data every 20 seconds.

Sets the unit of the current movement

speed of the radio, including km/h, mile/h,

Configuration Guide.

Default: km/h.

Note: This parameter is

available only when GPS

2.4).

and sea mile/h.

Speed Unit

Parameter	Description	Setting		
		feature is enabled.		
GPS Update	Sets the time interval at which the radio	Range : 1-60s. Default : 5s.		
Time	updates location information.	Note : This parameter is available only when GPS feature is enabled.		
GPS Display Unit	Sets the unit to display location information, including ddd.ddddd, ddd.mm, and ddd.mm.ss.	Default: ddd.ddddd.		

Step 2 Enable Call Location.

CPS Path: Conventional -> General Setting -> Accessories -> Call Location.

Parameters: Call Location and Display Type. Refer to CPS Help for detailed description.

Call Location
Display Type sixteen azimuth and distance -

With this feature enabled, the radio displays talker's location after the call sets up. The talker (transmitting radio) must enable Voice w/Location (Step 8 in section 2.4), otherwise the receiving radio will not display his/her location. The radio without positioning chip does not support Voice w/Location feature, thus it only displays other talker's location.

The radio displays the received location according to Display Type.

- Radios with positioning chip
 - > Sixteen Azimuth and Distance: To display sixteen azimuth and distance.
 - > Accurate Azimuth and Distance: To display accurate azimuth and distance.
 - > Talker Location: To display longitude and latitude.
- Radios without positioning chip

Talker Location: To display longitude and latitude.

Step 3 (Optional) Configure menus if you want to enable or disable GPS related features through radio menu.

CPS Path: Conventional -> General Setting -> Menu -> Accessories.

Parameters: See below figure. The radio without positioning chip displays Call Location and Query

Location menus only. Refer to CPS Help for detailed description.

Radio Information	Accessories
🗄 🦲 Common	IV BT
Conventional	BT Location
Setting	GPS
Accessories	GPS On/Off
	Positioning System
Ge One Touch Call / Menu	Query Location
UI Indication	Position View
ସ୍ ୬ Voice Notify 	GPS Msg
E- Zone	Call Location
🗄 🛄 Channel	GPS Generator
Analog Service	Voice w/Location
DMR Services	V Roam

Note

The Query Location is used to query location of the radios with GPS enabled. After obtaining the location, the radio with positioning chip displays distance, direction, longitude and latitude of the target radio, while the radio without positioning chip displays longitude and latitude only.

2.4 Configuring Parameters Related to Location Information Report

The radio automatically reports its location to the dispatch station after the following parameters are configured.

Step 1 Configure Control Center ID and Location Port to specify the target radio or repeater.

CPS Path: Conventional -> General Setting -> Network -> Radio Services.

Parameters: Control Center ID, Location Port and Identifier.

Radio Information	Radio Services						
Conventional		Control Center ID	1		1		
		Control Center IP	10.0.0.1		1		
		RRS Port	3002	* *	Identifier	115	
¶⊒ Menu & UI Indication		Location Port	3003	×	Identifier	116	
Voice Notify		TMS Port	5016	*			

ACaution

The Control Center ID must be unique and comply with the dial rules of the system.

Step 2 Configure the conditions under which the radio automatically reports location.

CPS Path: Conventional -> General Setting -> Accessories -> GPS -> GPS Trigger.

Parameters: See below figure. For parameter description, see the Table below.

		GPS Trigger	
Common Conventional Conventional Conventional Conventional Conventional Conventional Conventional Convention		Button Power On Power Off Time Distance Relationship Between Time and Distance Report Start Time 0000-00-00 00:00: Report Stop Time 0000-00-00 00:00: Report Stop Time 0000-00-00 00:00: Report Interval Time [day] 0 1 100 The Longest Report Time[day] 0 1 1 1	v 00 00 [minute] 1 v [minute] 1 [minute] 1 [minute] 1
Parameter		Description	Setting
Button	Sets whether programmed for the conf Checked key is pr Uncheck when th	er the radio reports location when the ed GPS Report key is pressed (See Step 3 figuration). d: The radio reports location when this pressed. ked: The radio doesn't report location his key is pressed.	Default : Unchecked
Power On	 Sets whether the radio reports location when it is powered on. Checked: The radio reports location when it is powered on. Unchecked: The radio doesn't report location when it is powered on. 		Default : Unchecked
Power Off	 Sets whether the radio reports location when it is powered off. Checked: The radio reports location when it is powered off. Unchecked: The radio doesn't report location when it is powered off. 		Default : Unchecked
Time	 Sets whether the radio reports location at preset time interval. This feature is subject to the following three parameters. Report Start Time: If this parameter is set to "0", 		Default: Unchecked Note: The three parameters are

Parameter	Description	Setting
	the radio reports location after programming.	available only when
	• Report Stop Time: If this parameter is set to "0", the radio periodically reports location, until it powers off or the system requests it to stop	Time is selected.
	 reporting. Report Interval Time: If this parameter is set to "0", the radio does not report location periodically. 	
Distance	 Sets whether the radio reports location when it moves beyond Report Interval Distance from the last reported position. With this feature enabled, the radio reports location it first receives after programming. the radio reports location as requested by the dispatch station. If no location information is available, the radio will report it when the information is available. 	Default: Unchecked Note: The Report Interval Distance is available only when Distance is selected.
Relationship Between Time and Distance	 Sets the conditions under which the radio reports the location if both Time and Distance are selected. Time Or Distance: the radio reports location when either the time-related or distance-related conditions are satisfied. Time And Distance: the radio reports location only when both the time-related and distance-related conditions are satisfied. 	Default: Time Or Distance Note: This parameter is available only when both Time and Distance are selected.
The Longest Report Time	Sets the interval time for the radio to automatically report GPS data to the control station when no GPS trigger conditions are satisfied.	Note: This parameter is available only when Relationship Between Time and

Parameter	Description	Setting
		Distance is set to
		Time And
		Distance.

Step 3 Configure a programmable key if you want the radio to report location when this key is pressed.

CPS Path: Conventional -> General Setting -> Buttons

Parameters: GPS Report. SK1 Short is taken as an example.

TK Short	Emergency On	•
SK1 Short	GPS Report	•
SK2 Short	Adjust Squelch Level	•

Step 4 Enable Quick GPS and Single GPS if a great number of radios are required to report location frequently.

CPS Path: Conventional -> General Setting -> Accessories -> GPS -> Quick GPS.

Parameters: See below figure. For parameter description, see the Table below.

The Quick GPS feature improves channel utilization and transmission efficiency. With this feature enabled, the system divides the Report Interval Time into different time slices with the same time length. Then the radio transmits GPS data in accordance with Report Order of its own time slices. In this way, GPS data of all radios under the same control station can be transmitted at the same interval.

Radio Information	Quick GPS			
Common Conventional Ceneral Setting		Quick GPS Time Synchronization Mode Report Start Time	GPS UART 0000-00-00 00:00:00	•
		Report Stop Time	0000-00-00 00:00:00	
ୁକ୍ତି Ul Indication କୁସ ୬ Voice Notify କୁସ ୧୦୦୦ ୧୦୦୦ ୧୦୦୦ ୧୦୦୦ ୧୦୦୦ ୧୦୦୦ ୧୦୦୦ ୧୦		Report Interval Time[s] Report Step[ms]	480	▼
Channel		Report Order Percentage of Channel Loading	1	Max value is 112

Note

The radio cannot report location through the programmed key after the Quick GPS feature is enabled.

Parameter	Description	Setting
Ouick GPS	Sets whether to enable the Quick GPS	Default: Unchecked
Quick of 5	feature.	Note: This parameter is

Parameter	Description	Setting
	• Checked: The Quick GPS is	available only when GPS
	enabled.	feature is enabled (See Step 1
	• Unchecked: The Quick GPS is	in section 2.2).
	disabled.	
Time Synchronization Mode	 Sets the mode of time synchronization to transmit GPS data through the Quick GPS feature. GPS UART: The time for GPS data transmission synchronizes with the UART of the GPS chip. 1PPS Pulse: The time for GPS data transmission synchronizes with the 1PPS pulse of the GPS chip. This option is available only for the radios that support the detection of the 1PPS pulse. 	Default : GPS UART Note : This parameter is available only when Quick GPS is selected.
Report Start Time	Set the start time to transmit GPS data through the Quick GPS feature.	Range: 0000-00-00 00:00:00 to 9999-12-31 23:59:59 Default: 0000-00-00 00:00:00 Note: This parameter is available only when Quick GPS is selected.
Report Stop Time	Set the stop time to transmit GPS data through the Quick GPS feature.	Range: 0000-00-00 00:00:00 to 9999-12-31 23:59:59 Default: 0000-00-00 00:00:00 Note: This parameter is available only when Quick GPS is selected.
Report Interval Time	Sets the time interval to transmit GPS data through the Quick GPS feature.	Range : 3s, 5s, 10s, 20s, 30s, 40s, 50s, 60s, 120s, 180s, 240s,

Parameter	Description	Setting
	See Percentage of Channel Loading for the relation among Report Interval Time, Report Step, Report Order and Percentage of Channel Loading.	 300s, 360s, 480s, 600s, 900s and 1200s. Default: 60s. Note: This parameter is available only when Quick GPS is selected.
Report Step	Sets the duration that the radio transmits GPS data through the Quick GPS feature. See Percentage of Channel Loading for the relation among Report Step, Report Interval Time, Report Order and Percentage of Channel Loading.	 Range: 300~2100ms Default: 480ms when Single GPS is disabled. 240ms and cannot be modified when Single GPS is enabled and Time Synchronization Mode is set as GPS UART. 120ms when Single GPS is enabled and Time Synchronization Mode is set as 1PPS Pulse. Note: This parameter is available only when Quick GPS is selected.
Report Order	Sets the order in which the radio transmits GPS data through the Quick GPS feature. See Percentage of Channel Loading for the relation among Report Order, Report Step, Report Interval Time and Percentage of Channel Loading.	 Range: 1~3600 Default: 1 Note: This parameter is available only when Quick GPS is selected. The report order for each

Parameter	Description	Setting
		radio under the same control station must be unique.
Percentage of Channel Loading	Sets percentage of slices to be used during Report Interval Time by all radios under the same control station to transmit GPS data through the Quick GPS feature. The remaining time slices will be reserved for the radio to respond the system request for location (like the radio transmits GPS data when it is powered on). For example, if Report Interval Time is set to 60s, and Report Step is set to 480ms, the time slice will be 125 (Report Interval Time/ Report Step). If Percentage of Channel Loading is set to 90%, the time slice available to transmit GPS data through the Quick GPS feature will be 112.	Range: 50%、67%、75%、80%、 90% Default: 90% Note: This parameter is available only when Quick GPS is selected.
Single GPS	This feature increases transmission speed of Quick GPS, and saves channel resources for GPS data transmission. With the feature enabled, the radio only reports longitude, latitude, reason for sending (in emergency mode or not) and source address when transmitting GPS data through Quick GPS. Any control station with the same frequency and color code as this radio can receive its GPS data.	 Default: Unchecked Note: This parameter is configurable only when Quick GPS is selected. The radio transmits GPS data to the control station no matter the GPS data is valid or not.

Parameter	Description	Setting
	• Checked: The Single GPS is	
	enabled.	
	• Unchecked: The Single GPS is	
	disabled.	

Step 5 Enable Single GPS Encrypt/Decrypt and set Single GPS Encrypt/Decrypt Key to encrypt or decrypt the single GPS data.

To use this feature, the Single GPS must be enabled (see Step 4 in this section).

- For the radio with positioning chip, the parameter names are **Single GPS Encrypt** and **Single GPS Encrypt Key**. The radio encrypts the GPS data before transmitting through Single GPS. When the encrypt keys are the same, the repeater repeats the GPS data and the receiving radio decrypts it.
- For the radio without positioning chip, the parameter names are **Single GPS Decrypt** and **Single GPS Decrypt Key**. The radio only decrypts the received single GPS data.

CPS Path: Conventional -> Digital Common -> Encrypt.

Parameters: Single GPS Encrypt/Decrypt and Single GPS Encrypt/Decrypt Key. For parameter description, see the Table below.

Radio Information		Singl	e GPS Encrypt	
Conventional		Single GP	S Encrypt Key	0123456789ABCDEF0123456789 ABCDEF
Channel Channel Analog Service Digital Common Asic		Over 1	the Air Encrypt	
Encrypt	No.	Key Alias	Key Valu	ie
Quick Text	1	Encrypt Key 1	55AA55	AA5555AA55AA5555AA55AA5555

Step 6 Configure a dedicated channel to transmit GPS data through the Quick GPS feature.

CPS Path: Conventional -> Channel -> Digital Channel -> CH DX

Parameters: Quick GPS. For parameter description, see the Table below.

Radio Information	Auto Start Scan	
Conventional	Quick GPS	
General Setting	Talk Around	
E Zone	De Oak 🗐	
E Channel	RX Only	
🖨 📇 Digital Channel	IP Multi-site Connect	
	Auto Start Roam	
- IT CH D2		
CH D3	VOX 📃	

Parameter	Description	Setting
Quick GPS	 Defines the current channel as dedicated channel for Quick GPS feature. Checked: The radio can only transmit GPS data through the Quick GPS feature on this channel. Other data, such as voice, text and RRS, cannot be transmitted. Unchecked: The radio transmits GPS data in normal way on this channel if the Quick GPS feature is also disabled on the radio. 	Default: Unchecked Note: This parameter is available only when the Quick GPS feature is enabled and Forward To PC (CPS Path: Conventional -> General Setting -> Network -> Radio to PC Network) is deselected.

Step 7 Set the Location Info Priority if BT Location is enabled.

CPS Path: Conventional -> General Setting -> Accessories -> BT Location.

Parameters: Location Info Priority. For parameter description, see the Table below.

Parameter	Description	Setting
	Sets the priority of location data the radio sends to the dispatch station.	Default : GPS Note:
Location	• BT Location: The radio first sends the BT location data to the dispatch station.	• This parameter is available only when BT Location is
Priority	 GPS: The radio first sends the GPS location data to the dispatch station. GPS+BT Location: The radio sends both 	 For more about BT Location feature, refer to
	the GPS and BT location data to the dispatch station.	DMR Conventional Radio_BT_User Manual.

Step 8 Enable Voice w/Location, and enable or disable the RSSI Report.

CPS Path: Conventional -> General Setting -> Accessories -> Location Application. **Parameters**: RSSI Report, Voice w/Location, PTT and Time. For parameter description, see the Table below.

Radio Information	Voice w/Location		-
Conventional		Voice w/Location 🔽 PTT 🔲	
Setting		Time [s] 60	×
Buttons	=		

Parameter	Description	Setting
RSSI Report	With this feature enabled, the radio reports RSSI with location to the dispatch station for evaluation of area signal strength.	Default : Unchecked. Note : This parameter is available only when GPS is selected.
Voice w/Location	With this feature enabled, the radio reports location according to PTT operation or preset time. If disabled, the radio does not report location when user holds down PTT to transmit voice. Then the dispatcher will not know location of the radio.	 Default: Unchecked Note: This parameter is available only when GPS is selected. When BT Location is enabled, the Location Info Priority (Step 7) must be set as GPS.
PTT	 Sets whether the radio reports location once when user holds down PTT to transmit voice. Checked: The radio reports location once when user holds down PTT to transmit voice. Unchecked: The radio does not report location when user holds down PTT to transmit voice. 	Default : Unchecked Note : This parameter is available only when Voice w/Location is selected.
Time	Sets the time interval for the radio to report location after user holds down PTT to transmit voice. The radio reports location once after user holds down PTT to transmit voice, and then reports location at this preset interval, until the user	Range: 3~230s Default: 60s Note: This parameter is available only when Voice w/Location is

Parameter	Description	Setting
	releases PTT.	selected and PTT is
		deselected.

Step 9 Configure the Location Info Revert Channel.

CPS Path: Conventional -> Channel -> Digital Channel -> CH DX -> TX.

Parameters: Location Info Revert Channel.

The radio may delay reporting location on current channel if it is occupied by other radios

transmitting voice or data signals. To solve this issue, you can set one channel for the radio to report

the location. After transmission, the radio switches back to the previous channel.

1	Гх
Transmit Frequency [MHz]	403.000000
Tx Contact Name	🚑 Call 1 👻
Location Info Revert Channel	🚾 CH D2 👻
RRS Revert Channel	None 👻
Battery Info Revert Channel	None 👻
Emergency System	DigitalSys 1 🔹

Step 10 (Optional) Enable the In Call Location Revert feature.

CPS Path: Conventional -> Digital Common -> Basic -> Miscellaneous.

Parameters: In Call Location Revert. For parameter description, see the Table below.



Parameter	Description	Setting
	• Unchecked: The radio reports location after the	duplex call.
	voice is received.	

Caution

This feature does not work if Location Info Revert Channel is set as Current.

3. Application

This chapter describes the GPS applications on the radio.

• Time Synchronization

To allow the radio to keep its time clock synchronized with the satellite time source, go to "Common -> RTC" in the CPS, and set Priority Time Source to GPS Timing.

- Viewing the location information
- To view the location information, go to "Menu -> Accessories -> GPS -> Position". The real-time location
 information includes the longitude, latitude, speed, altitude, time, date and the number of visible satellites. If
 TF Card GPS Record is enabled, user can use Smart Dispatch to read GPS data in the TF card and view radio
 tracks on map.
- Viewing talker's location during a call

To view talker's location during a call, go to "Menu -> Accessories -> GPS -> Call Location". After the call sets up, the radio displays taker's location if the talker (transmitting radio) enables the Voice w/Location.

• Sending the location information

To send the location information, go to "Menu -> Accessories -> GPS -> Position -> GPS Msg". The user can view location information, and then send it to another radio as a message. The receiving user can locate the sending radio using the third-party application (for example, map).

In addition, the radio automatically reports location to the preset target ID when it enters emergency mode or the telemetry feature is activated (the prerequisite is that Action parameter must be set to Send Status w/GPS Message Command).

• Querying Location

To query location of the radio with GPS enabled, go to "Menu -> Accessories -> GPS -> Query Location". After obtaining location data, the radio with positioning chip displays distance, direction, longitude and latitude of the target radio, while the radio without positioning chip displays longitude and latitude only.

• Reporting location to the dispatch station

The radio automatically reports location to the dispatch station when the preset conditions are satisfied, allowing the dispatch station to locate it for dispatch purpose.

Abbreviations

Abbreviation	Full Name
COMPASS	BeiDou Navigation Satellite System
CPS	Customer Programming Software
GPS	Global Positioning System
DMR	Digital Mobile Radio
GLONASS	Global Navigation Satellite System
GPS	Global Positioning System



is the trademark or registered trademark of Hytera Communications Corporation Limited. © 2018 Hytera Communications Corporation Limited. All Rights Reserved.

Address: HYT Tower, Hi-Tech Industrial Park North, Beihuan RD., Nanshan District, Shenzhen, China Postcode:518057 http://www.hytera.com